


REMOTE CALL RADIO




2. Instruction


▪ Key Function

- To turn on the radio. Press the power On/Off button for 5 seconds to turn on the radio. To turn off the radio press and hold the power button
- Volume Controls. To turn up the volume on the radio slide the control to "+". To turn down the volume on the radio slide the control to "-".
- Radio Control. To select frequency rotate the dial to preferred station. Scroll right to move up frequency. Scroll left to move down frequency.
- Projector Control. Press button to turn on projector. Press button to turn off projector.

SIDE (LEFT)



TOP



Remote Call Radio

Thank you for purchasing Remote Call Radio
For best use for this device we recommend
carefully reading this user manual and keeping
it for your records.

PACKAGE CONTAINS:

- Wireless Radio
- AAA plus batteries

Charging the batteries.

This device is designed to be used with triple A batteries.
One set is included.

- Do not disassemble throw away or damage the radio.
- Store the radio in a dry place, keeping it away from damp environments
- Please do not discard the radio. Consult your local waste collection.



It may damage your hearing if you listen with high volume for a long time. It is recommended you use the lowest volume possible for speaking and listening to music.